

TONTABELLEN FÜR SIRENEN, 24VDC AND 230VAC | TONETABLES FOR SOUNDER, 24VDC AND 230VAC

SPEZIFIKATIONEN / SPECIFICATIONS

Primary tone	Secondary tone	Code	Tone description	Main Application	Roshni / Roshni LP @24VDC		Flashni @24VDC		Squashni @24VDC		Askari @24VDC		Symphoni H0 @24VDC		
					mA	dB	mA	dB	mA	dB	mA	dB	mA	dB	
1	14	11111	Alternating 800 & 970	2Hz (250ms-250ms)	BS Fire tone	16	101	68	100	18	93	18	95	240	113
2	14	11110	Sweep 800 to 970	7Hz (7/s)	BS Fire tone	16	102	68	101	18	93	18	97	230	113
3	14	11101	Sweep 800 to 970	1Hz (1/s)	BS Fire tone	16	102	68	101	18	93	18	97	240	114
4	14	11100	Continuous 2850	Steady		30	111	82	110	32	102	32	105	210	119
5	4	11011	Sweep 2400 to 2850	7Hz		28	111	80	110	30	102	30	106	210	118
6	4	11010	Sweep 2400 to 2850	1Hz		28	111	80	110	30	102	30	106	210	120
7	14	11001	Slow whoop 300 to 1200	3s sweep, 0.5 s silence, then repeat	BS Fire tone	18	99	70	98	20	91	20	96	240	113
8	14	11000	Sweep 1200 to 500	1Hz	Din tone	14	99	66	98	16	91	16	95	240	112
9	4	10111	Alternating 2400 & 2850	2Hz (250ms-250ms)		28	110	80	109	30	101	30	105	210	117
10	14	10110	Intermittent 970	0.5Hz (1s On/1s Off)		10	101	62	100	12	91	12	93	250	113
11	14	10101	Alternating 800 & 970	1Hz (500ms-500ms)	BS Fire tone	16	101	68	100	18	92	18	95	230	113
12	4	10100	Intermittent 2850	0.5Hz (1s On/1s Off)		22	110	74	109	24	98	24	105	210	117
13	14	10011	Intermittent 970	0.8Hz (250ms On/1s Off)		6	97	58	96	8	87	8	90	260	113
14	14	10010	Continuous 970	Steady	BS Fire tone	18	102	70	101	20	92	20	94	250	112
15	14	10001	Alternating 554 & 440	100ms-400ms	French fire tone	10	94	62	93	12	87	12	91	200	108
16	16	10000	Intermittent 660	3.3Hz (150ms On/150ms Off)	Swedish fire tone	7	87	59	86	9	88	9	88	230	111
17	17	01111	Intermittent 660	0.28Hz(1.8s On/1.8s Off)	Swedish fire tone	10	89	62	88	12	92	12	90	230	111
18	18	01110	Intermittent 660	0.05Hz (6.5Hz On/13s Off)	Swedish fire tone	12	89	64	88	14	93	14	91	240	111
19	19	01101	Continuous 660	Steady	Swedish fire tone	12	90	64	89	14	93	14	91	220	110
20	20	01100	Alternating 554 & 440	0.5Hz (1s On/1s Off)	Swedish fire tone	11	97	63	96	13	90	13	91	210	108
21	21	01011	Intermittent 660	1Hz (500ms-500ms)	Swedish fire tone	8	88	60	87	10	90	10	89	230	111
22	14	01010	Intermittent 2850	4Hz (150ms On/100ms Off)	Pelican crossing	20	110	72	109	22	98	22	105	210	116
23	14	01001	Sweep 800 to 970	50Hz	BS Fire tone	16	102	68	101	18	92	18	96	230	112
24	4	01000	Sweep 2400 to 2850	50Hz		23	111	75	110	25	102	25	106	190	116
25	25	00111	Intermittent 970	3 x 500ms pulses followed by 1.5s silence then repeat	ISO 8201	12	100	64	99	14	88	14	92	260	113
26	26	00110	Intermittent 2850	3 x 500ms pulses followed by 1.5s silence then repeat	ISO 8201	18	109	70	108	20	97	20	104	220	117
27	27	00101	Continuous 4000	Steady		33	84	85	83	35	98	35	101	220	108
28	10	00100	Alternating 800 & 970	2Hz (250ms-250ms)	BS Fire tone	15	101	67	100	17	92	17	95	230	113
29	33	00011	Alternating 990 & 650	2Hz (250ms-250ms) (Symphoni tones)	BS Fire tone	19	100	71	99	18	92	17	97	230	111
30	35	00010	Alternating 510 & 610	2Hz (250ms-250ms) (Squashni Micro tones)	BS Fire tone	13	97	65	96	13	90	12	98	190	111
31	31	00001	Sweep 300 to 1200	1Hz		19	97	71	96	20	91	13	96	230	111
32	32	00101	Continuous 4000	Steady		33	84	85	83	35	98	12	99	220	108